


Pneumatic Tube Fittings

XPDJ




ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPDJ 04	XPDJ 08-06
XPDJ 06	XPDJ 10-08
XPDJ 08	XPDJ 12-10
XPDJ 10	
XPDJ 12	
XPDJ 06-04	

XPSJ



ΦD1
ΦD2

MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPSJ 06-04	XPSJ 1/4-5/32
XPSJ 08-06	XPSJ 5-16-1/4
XPSJ 10-08	XPSJ 3/8-5-16
XPSJ 12-10	XPSJ 1-2-3/8

XPTJ



ΦD1
ΦD2

MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPTJ 06-04	XPTJ 1/4-5/32
XPTJ 08-06	XPTJ 5/16-1/4
XPTJ 10-08	XPTJ 3/8-5/16
XPTJ 12-10	XPTJ 1/2-3/8

XPP



ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPP 04	XPP 5/32
XPP 06	XPP 3/16
XPP 08	XPP 1/4
XPP 10	XPP 5/16
XPP 12	XPP 3/8
XPP 16	XPP 1/2

XPIG



ΦD1
ΦD2

MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPIG 06-04	XPIG 3/16-5/32
XPIG 08-06	XPIG 1/4-5/32
XPIG 10-08	XPIG 1/4-3/16
XPIG 12-10	XPIG 5/16-1/4
XPIG 16-12	XPIG 3/8-5/16
	XPIG 1/2-3/8

XPM



ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPM 04	XPM 5/32
XPM 06	XPM 3/16
XPM 08	XPM 1/4
XPM 10	XPM 5/16
XPM 12	XPM 3/8
XPM 14	XPM 1/2
XPM 16	

XPZA



ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPZA 04	XPZA 5/32
XPZA 06	XPZA 3/16
XPZA 08	XPZA 1/4
XPZA 10	XPZA 5/16
XPZA 12	XPZA 3/8
	XPZA 1/2

XPKG



ΦD1
ΦD2

MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPKG 06-04	XPKG 3/16-5/32
XPKG 08-04	XPKG 1/4-5/32
XPKG 08-06	XPKG 5/16-5/32
XPKG 10-06	XPKG 3/16-3/16
XPKG 10-08	XPKG 5/16-1/4
	XPKG 3/8-1/4
	XPKG 3/8-5/16

XPKE



ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPKE 04	XPKE 5/32
XPKE 06	XPKE 3/16
XPKE 08	XPKE 1/4
	XPKE 5/16

XPLM




ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPLM 04	
XPLM 06	
XPLM 08	
XPLM 10	
XPLM 12	

Pneumatic Tube Fittings

XPHT(2)




ΦD
T

MODEL(ΦD-T)

Tube(Metric)-Thread(R)	Tube(Metric)-Thread(R)
XPHT04 -01(2)	XPHT08 -04(2)
XPHT04 -02(2)	XPHT10 -01(2)
XPHT06 -01(2)	XPHT10 -02(2)
XPHT06 -02(2)	XPHT10 -03(2)
XPHT06 -03(2)	XPHT10 -04(2)
XPHT08 -01(2)	XPHT12 -02(2)
XPHT08 -02(2)	XPHT12 -03(2)
XPHT08 -03(2)	XPHT12 -04(2)

XPLGJ




ΦD
T

MODEL(ΦD-T)

Tube(Metric)-Thread(R)	Tube(Metric)-Thread(R)
XPHT04 -01(3)	XPHT08 -04(3)
XPHT04 -02(3)	XPHT10 -01(3)
XPHT06 -01(3)	XPHT10 -02(3)
XPHT06 -02(3)	XPHT10 -03(3)
XPHT06 -03(3)	XPHT10 -04(3)
XPHT08 -01(3)	XPHT12 -02(3)
XPHT08 -02(3)	XPHT12 -03(3)
XPHT08 -03(3)	XPHT12 -04(3)

XPPF




ΦD

MODEL(ΦD)

Tube(Metric)
XPPF04
XPPF06
XPPF07
XPPF08
XPPF10
XPPF12

XPU



ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPU 04	XPU 5/32
XPU 06	XPU 3/16
XPU 08	XPU 1/4
XPU 10	XPU 5/16
XPU 12	XPU 3/8
XPU 14	XPU 1/2
XPU 16	

XPV



ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPV 04	XPV 5/32
XPV 06	XPV 3/16
XPV 08	XPV 1/4
XPV 10	XPV 5/16
XPV 12	XPV 3/8
XPV 14	XPV 1/2
XPV 16	

XPE




ΦD

MODEL(ΦD)

Tube(Metric)	Tube(Inch)
XPE 04	XPE 5/32
XPE 06	XPE 3/16
XPE 08	XPE 1/4
XPE 10	XPE 5/16
XPE 12	XPE 3/8
XPE 14	XPE 1/2
XPE 16	

XPY




ΦD

MODEL(ΦD-T)

Tube(Metric)	Tube(Inch)
XPY 04	XPY 5/32
XPY 06	XPY 3/16
XPY 08	XPY 1/4
XPY 10	XPY 5/16
XPY 12	XPY 3/8
	XPY 1/2

XPG




ΦD1
ΦD2

MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPG 06-04	XPG 3/16-5/32
XPG 08-04	XPG 1/4-5/32
XPG 08-06	XPG 1/4-3/16
XPG 10-06	XPG 5/16-1/4
XPG 10-08	XPG 3/8-5/16
XPG 12-10	XPG 1/2-3/8
XPG 16-12	
XPG 16-14	

XPGE



ΦD1
ΦD2

MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPGE 06-04	XPGE 1/4-5/32
XPGE 08-06	XPGE 5/16-1/4
XPGE 10-08	XPGE 3/8-5/16
XPGE 12-10	XPGE 1/2-3/8
XPGE 16-12	

XPEG



ΦD1
ΦD2

MODEL(ΦD1-ΦD2)

Tube(Metric)	Tube(Inch)
XPEG 06-04	XPEG 1/4-5/32
XPEG 08-06	XPEG 5/16-1/4
XPEG 10-08	XPEG 3/8-5/16
XPEG 12-10	XPEG 1/2-3/8
XPEG 16-12	