









Pneumatic Tube Fittings

XPDJ	MODEL(ΦD)		XPSJ	MODEL(ΦD1-ΦD2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPDJ 04	XPDJ 08-06		XPSJ 06-04	XPSJ 1/4-5/32
	XPDJ 06	XPDJ 10-08		XPSJ 08-06	XPSJ 5-16-1/4
	XPDJ 08	XPDJ 12-10		XPSJ 10-08	XPSJ 3/8-5-16
	XPDJ 10			XPSJ 12-10	XPSJ 1-2-3/8
	XPDJ 12				
	XPDJ 06-04				

XPTJ	MODEL(ΦD1-ΦD2)		XPP	MODEL(ΦD)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPTJ 06-04	XPTJ 1/4-5/32		XPP 04	XPP 5/32
	XPTJ 08-06	XPTJ 5/16-1/4		XPP 06	XPP 3/16
	XPTJ 10-08	XPTJ 3/8-5/16		XPP 08	XPP 1/4
	XPTJ 12-10	XPTJ 1/2-3/8		XPP 10	XPP 5/16
				XPP 12	XPP 3/8
		XPP 16	XPP 1/2		



XPIG	MODEL(ΦD1-ΦD2)		XPM	MODEL(ΦD)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPIG 06-04	XPIG 3/16-5/32		XPM 04	XPM 5/32
	XPIG 08-06	XPIG 1/4-5/32		XPM 06	XPM 3/16
	XPIG 10-08	XPIG 1/4-3/16		XPM 08	XPM 1/4
	XPIG 12-10	XPIG 5/16-1/4		XPM 10	XPM 5/16
	XPIG 16-12	XPIG 3/8-5/16		XPM 12	XPM 3/8
		XPIG 1/2-3/8		XPM 14	XPM 1/2
		XPM 16			

XPZA	MODEL(ΦD)		XPKG	MODEL(ΦD1-ΦD2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPZA 04	XPZA 5/32		XPKG 06-04	XPKG 3/16-5/32
	XPZA 06	XPZA 3/16		XPKG 08-04	XPKG 1/4-5/32
	XPZA 08	XPZA 1/4		XPKG 08-06	XPKG 5/16-5/32
	XPZA 10	XPZA 5/16		XPKG 10-06	XPKG 3/16-3/16
	XPZA 12	XPZA 3/8		XPKG 10-08	XPKG 5/16-1/4
		XPZA 1/2		XPKG 3/8-1/4	XPKG 3/8-5/16



XPK	MODEL(ΦD)		XPLM	MODEL(ΦD)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPK 04	XPK 5/32		XPLM 04	
	XPK 06	XPK 3/16		XPLM 06	
	XPK 08	XPK 1/4		XPLM 08	
		XPK 5/16		XPLM 10	
			XPLM 12		



Pneumatic Tube Fittings

XPHT(2)	MODEL(ΦD-T)		XPLGJ	MODEL(ΦD-T)	
	Tube(Metric)-Thread(R)	Tube(Metric)-Thread(R)		Tube(Metric)-Thread(R)	Tube(Metric)-Thread(R)
	XPHT04 -01(2)	XPHT08 -04(2)		XPHT04 -01(3)	XPHT08 -04(3)
	XPHT04 -02(2)	XPHT10 -01(2)		XPHT04 -02(3)	XPHT10 -01(3)
	XPHT06 -01(2)	XPHT10 -02(2)		XPHT06 -01(3)	XPHT10 -02(3)
	XPHT06 -02(2)	XPHT10 -03(2)		XPHT06 -02(3)	XPHT10 -03(3)
	XPHT06 -03(2)	XPHT10 -04(2)		XPHT06 -03(3)	XPHT10 -04(3)
	XPHT08 -01(2)	XPHT12 -02(2)		XPHT08 -01(3)	XPHT12 -02(3)
	XPHT08 -02(2)	XPHT12 -03(2)		XPHT08 -02(3)	XPHT12 -03(3)
	XPHT08 -03(2)	XPHT12 -04(2)		XPHT08 -03(3)	XPHT12 -04(3)

XPPF	MODEL(ΦD)		XPU	MODEL(ΦD)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPPF04			XPU 04	XPU 5/32
	XPPF06			XPU 06	XPU 3/16
	XPPF07			XPU 08	XPU 1/4
	XPPF08			XPU 10	XPU 5/16
	XPPF10			XPU 12	XPU 3/8
	XPPF12			XPU 14	XPU 1/2
		XPU 16			

XPV	MODEL(ΦD)		XPE	MODEL(ΦD)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPV 04	XPV 5/32		XPE 04	XPE 5/32
	XPV 06	XPV 3/16		XPE 06	XPE 3/16
	XPV 08	XPV 1/4		XPE 08	XPE 1/4
	XPV 10	XPV 5/16		XPE 10	XPE 5/16
	XPV 12	XPV 3/8		XPE 12	XPE 3/8
	XPV 14	XPV 1/2		XPE 14	XPE 1/2
	XPV 16			XPE 16	

XPY	MODEL(ΦD-T)		XPG	MODEL(ΦD1-ΦD2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPY 04	XPY 5/32		XPG 06-04	XPG 3/16-5/32
	XPY 06	XPY 3/16		XPG 08-04	XPG 1/4-5/32
	XPY 08	XPY 1/4		XPG 08-06	XPG 1/4-3/16
	XPY 10	XPY 5/16		XPG 10-06	XPG 5/16-1/4
	XPY 12	XPY 3/8		XPG 10-08	XPG 3/8-5/16
		XPY 1/2		XPG 12-10	XPG 1/2-3/8
		XPG 16-12			
		XPG 16-14			

XPGE	MODEL(ΦD1-ΦD2)		XPEG	MODEL(ΦD1-ΦD2)	
	Tube(Metric)	Tube(Inch)		Tube(Metric)	Tube(Inch)
	XPGE 06-04	XPGE 1/4-5/32		XPEG 06-04	XPEG 1/4-5/32
	XPGE 08-06	XPGE 5/16-1/4		XPEG 08-06	XPEG 5/16-1/4
	XPGE 10-08	XPGE 3/8-5/16		XPEG 10-08	XPEG 3/8-5/16
	XPGE 12-10	XPGE 1/2-3/8		XPEG 12-10	XPEG 1/2-3/8
	XPGE 16-12			XPEG 16-12	